



ORIGINAL	REPLACEMENT
STANDBY	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	AV
+10 / CH. LIST	-/--
PRO.	
ZOOM	
SUBPAGE	
TEXT / SETUP	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SLEEP	SLEEP
INFO	INFO
EPG	EPG

ORIGINAL	REPLACEMENT
FAV / D. MENU	FAV
ASPECT	
HOLD	
RED / DISP.	RED
GREEN / ANGLE	GREEN
YELLOW / SLOW	YELLOW
BLUE / TITLE	BLUE
AUDIO / INDEX	SHIFT+MUTE
CANCEL / A-B	SHIFT+EXIT
NICAM	SHIFT+1
GO TO	SHIFT+ -/--
REVEAL / REPEAT	SHIFT+
SIZE	SHIFT+
SUBTITLE / SUB. T.	SHIFT+
SKIP PREV.	SHIFT+ P-
SKIP NEXT	SHIFT+ P+
STEP	SHIFT+SLEEP
EJECT / MED. - PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY/PAU. / M. - PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

