



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	AV
DISPLAY	
SIZE	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
INDEX	INFO
HOLD	
RED / ZOOM	RED
GREEN / TITLE	GREEN
YELLOW / GO TO	YELLOW
BLUE / SCREEN	BLUE

[illegible]