



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
CLEAR	EXIT
SOURCE	 / SOURCE
SHUFFLE	-/--
DISPLAY	
MODE	
PROGRAM	
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
RETURN	BACK
PURE DIRECT	INFO
HOME	EPG
NOW PLAYING	FAV
EJECT	 / NET TV
PAUSE	
STOP	 / SMART
PLAY	YELLOW
REW	GREEN

[illegible]