



ORIGINAL	SUPERIOR
STANDBY / ON	POWER
MUTE	MUTE
MENU	MENU
OFF	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT MODE	 / SOURCE
+10	-/--
DISPLAY	
ENHANCER	
VOL. MODE	
TEST	
VOLUME +/-	VOL +/-
SKIP PREV/NEXT	P +/-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
SLEEP	SLEEP
SUR. DECODE	TV/DTV
SEARCH	INFO
MEMORY	EPG
PAUSE	

ORIGINAL	SUPERIOR
STOP	 / SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE
AUX 1/2/3	SHIFT+1/2/3
FM	SHIFT+4
DVD	SHIFT+5
STB	SHIFT+6
TV	SHIFT+7
CH. LEVEL	SHIFT+ -/--
AUTO SETUP	SHIFT+ 
PRESET PREV./NEXT	SHIFT+ DOWN/UP
A - E/CAT. +/-	SHIFT+ LEFT/RIGHT
CH +/-	SHIFT+ P +/-
STEREO	SHIFT+INFO
MY SUR.	SHIFT+EPG
PRESET/TUNE / A - E	SHIFT+FAV
MOVIE	SHIFT+ 
MUSIC	SHIFT+ 
SPORTS	SHIFT+ 
3 BEAM	SHIFT+RED
5 BEAM	SHIFT+GREEN
ST. +3 BEAM	SHIFT+YELLOW
MY BEAM	SHIFT+BLUE

