



| ORIGINAL        | SUPERIOR                                                                                   |
|-----------------|--------------------------------------------------------------------------------------------|
| SYSTEM POWER    | POWER                                                                                      |
| MUTE            | MUTE                                                                                       |
| MENU            | MENU                                                                                       |
| EXIT            | EXIT                                                                                       |
| 1 / STEREO      | 1                                                                                          |
| 2 / HALL 1      | 2                                                                                          |
| 3 / HALL 2      | 3                                                                                          |
| 4 / CHURCH      | 4                                                                                          |
| 5 / JAZZ        | 5                                                                                          |
| 6 / ROCK        | 6                                                                                          |
| 7 / MUSIC       | 7                                                                                          |
| 8 / ENTERTAIN   | 8                                                                                          |
| 9 / MOVE        | 9                                                                                          |
| 0 / THX         | 0                                                                                          |
| +100 / NIGHT    |  / SOURCE |
| +10 / DOLBY/DTS | -/-                                                                                        |
| ON SCREEN       |           |
| STRAIGHT EFFECT |           |
| EX/ES           |           |
| VOLUME+         | VOL+                                                                                       |
| VOLUME -        | VOL -                                                                                      |
| UP              | UP                                                                                         |
| DOWN            | DOWN                                                                                       |
| LEFT            | LEFT                                                                                       |
| RIGHT           | RIGHT                                                                                      |

| ORIGINAL    | SUPERIOR                                                                                   |
|-------------|--------------------------------------------------------------------------------------------|
| ENTER       | OK                                                                                         |
| SLEEP       | SLEEP                                                                                      |
| SPEAKERS A  | GREEN                                                                                      |
| SPEAKERS B  | BLUE                                                                                       |
| STANDBY     | SHIFT+POWER                                                                                |
| CABLE       | SHIFT+1                                                                                    |
| CD          | SHIFT+2                                                                                    |
| CD - R      | SHIFT+3                                                                                    |
| DTV/LD      | SHIFT+4                                                                                    |
| DVD         | SHIFT+5                                                                                    |
| DVR         | SHIFT+6                                                                                    |
| MD/TAPE     | SHIFT+7                                                                                    |
| MULTI CH IN | SHIFT+8                                                                                    |
| PHONO       | SHIFT+9                                                                                    |
| SAT         | SHIFT+0                                                                                    |
| TUNER       | SHIFT+  |
| V - AUX     | SHIFT+  |
| VCR 1       | SHIFT+  |
| VCR 2       | SHIFT+  |
|             |                                                                                            |
|             |                                                                                            |
|             |                                                                                            |
|             |                                                                                            |
|             |                                                                                            |
|             |                                                                                            |
|             |                                                                                            |

