ORIGINAL	SUPERIOR
POWER	POWER
VOCAL FADER/MULTIPLEX	MUTE
SET	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
EDIT / CHECK	/ SOURCE
+10	-/--
GEQ	
RANDOM	
T – BASS	
CLOCK	
VOLUME UP	VOL+
VOLUME DOWN	VOL -
TUNING UP	P+
TUNING DOWN	P -
DISC DIRECT PLAY 1	UP
DISC DIRECT PLAY 3	LEFT
DISC DIRECT PLAY 2	RIGHT
KARAOKE ENTER	OK
REPEAT / MONO TUNER	BACK
SLEEP	SLEEP
DIRECTION / PRESET	TV/DTV
PRGM	FAV
OPEN / CLOSE	/ NET TV

ORIGINAL	SUPERIOR
PAUSE	
STOP	/ SMART
REC / REC MUTE	RED
REW	GREEN
PLAY	YELLOW
FWD	BLUE
TIMER	SHIFT+POWER
CD	SHIFT+1
VIDEO / AUX	SHIFT+2
TUNER BAND	SHIFT+3
TAPE DACK 1/2	SHIFT+4