ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
VIDEO	/ SOURCE
10+	-/--
OSD	
GOTO	
SETUP	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
SLOW	SLEEP
P/N	TV/DTV
TITLE	INFO
PROGRAM	EPG

ORIGINAL	SUPERIOR
RAN	FAV
OPEN/CLOSE	/ NET TV
STOP	/ SMART VIDEO
REW	GREEN
PLAY/PAUSE	YELLOW
FWD	BLUE
AUDIO	SHIFT+MUTE
PBC	SHIFT+MENU
L/R	SHIFT+
ZOOM	SHFIT+
ANGLE	SHIFT+
A – B	SHIFT+
REPEAT	SHIFT+BACK
STEP	SHIFT+SLEEP