ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
MENU/INFO	MENU
P	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
MODE	/ SOURCE
BT PAIR	-/--
EQ	
+	VOL+
-	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK (SCAN)	OK
REPEAT/RANDOM	BACK
SLEEP/SNOOZE	SLEEP
ALARM	TV/DTV
STOP	/ SMART
PLAY/PAUSE	YELLOW

ORIGINAL	SUPERIOR