ORIGINAL	SUPERIOR
⏻	POWER
MENU	MENU
CANCEL	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
ATR	/ SOURCE
CLOCK / COUNTER	-/--
SHOWVIEW / PROGR.	
CHANNEL/TRACKING+	P+
CHANNEL/TRACKING -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
CALL	BACK
TIMER REC.	SLEEP
TV / VCR	TV/DTV
INDEX	INFO
COUNTER MEMORY	EPG
COUNTER RESET	FAV
EJECT	/ NET TV
PAUSE / STILL	
STOP	/ SMART
REC / OTR	RED

ORIGINAL	SUPERIOR
REW /	GREEN
PLAY / SLOW	YELLOW
FWD /	BLUE