ORIGINAL	SUPERIOR
ON / SOURCE	POWER
MUTING	MUTE
DVD / HDP	4
TV / CBL	5
VCR	6
VOL+	VOL+
VOL -	VOL -
SKIP NEXT/CH+	P+
SKIP PREV/CH -	P -
CHANNEL+	UP
CHANNEL -	DOWN
PAUSE / A/B	⏸
STOP	■ / SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE

ORIGINAL	SUPERIOR