ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
OPTION	MENU
AUX	1
BLUE RAY	2
CBL/SAT	3
CD	4
DVD	5
FM	6
GAME	7
INTERNET RADIO	8
IPOD/USB	9
MEDIA PLAYER	0
NETWORK	/ SOURCE
TV AUDIO	-/--
SETUP	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT/TUN+	P+
SKIP PREV/TUN -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK

ORIGINAL	SUPERIOR
BACK	BACK
SLEEP	SLEEP
INFO	INFO
PLAY/PAUSE	YELLOW
FAVORITE STATION 1	SHIFT+1
FAVORITE STATION 2	SHIFT+2
FAVORITE STATION 3	SHIFT+3
CH/PAGE+	SHIFT+ P+
CH/PAGE -	SHIFT+ P -