ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SAT	/ SOURCE
/ FIND	-/--
/ MEDIA	
TMS	
VOL+	VOL+
VOL -	VOL -
PAGE UP	P+
PAGE DOWN	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
/ RECALL	BACK
	SLEEP
TV / RADIO	TV/DTV
INFO	INFO
EDV	EPG
FAV	FAV

ORIGINAL	SUPERIOR
RED / AUDIO	RED
GREEN / V. FORMAT	GREEN
YELLOW / TXT	YELLOW
BLUE / TV/STB	BLUE
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
F. B.	SHIFT+GREEN
PLAY	SHIFT+YELLOW
F. B.	SHIFT+BLUE