ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SAT	-/--
HOME	
SUB	
VOL+	VOL+
VOL -	VOL -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
TV/RADIO	TV/DTV
INFO	INFO
FAV	FAV
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
RED	SHIFT+RED

ORIGINAL	SUPERIOR