| ORIGINAL | SUPERIOR |
|---|---|
| POWER | POWER |
| MUTE | MUTE |
| MENU | MENU |
| CLEAR | EXIT |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| MODE | / SOURCE |
| +10 | -/-- |
| VIDEO/Y | |
| ZOOM | |
| SETUP | |
| SUBTITLE | |
| VOLUME+ | VOL+ |
| VOLUME - | VOL - |
| SKIP NEXT | P+ |
| SKIP PREV | P - |
| UP | UP |
| DOWN | DOWN |
| LEFT | LEFT |
| RIGHT | RIGHT |
| ENTER | OK |
| REPEAT | BACK |
| LANGUAGE | SLEEP |
| NTSC/PAL | TV/DTV |
| TITLE | INFO |

| ORIGINAL | SUPERIOR |
|---|---|
| A – B RPT | EPG |
| REPLAY | FAV |
| OPEN/CLOSE | / NET TV |
| PAUSE | |
| STOP | / SMART |
| REW | GREEN |
| PLAY | YELLOW |
| FWD | BLUE |
| AUDIO | SHIFT+MUTE |
| SEARCH | SHIFT+EXIT |
| 3D | SHIFT+3 |
| ANGLE | SHIFT+ |
| P>P | SHIFT+ |
| SLOW | SHIFT+LEFT |
| SLOW | SHIFT+RIGHT |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |