ORIGINAL	SUPERIOR
⏻	POWER
AUDIO	MUTE
⌂ / HOME	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DISC MENU	-/--
SUBTITLE	▤
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
↩ / BACK	BACK
INFO / MENU	INFO
MUSIC ID	EPG
TITLE / POP UP	FAV
OPEN/CLOSE	⏏ / NET TV
PAUSE	⏸
STOP	■ / SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE

ORIGINAL	SUPERIOR
⟲ / REPEAT	SHIFT+BACK
RED	SHIFT+RED
GREEN	SHIFT+GREEN
YELLOW	SHIFT+YELLOW
BLUE	SHIFT+BLUE