ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
Q.MENU	MENU
/ EXIT	EXIT
/ SOURCE	/ SOURCE
STILL	-/--
PICTURE	
RATIO	
BLANK	
VOL+	VOL+
VOL -	VOL -
PAGE+	P+
PAGE -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
↩	BACK
SLEEP	SLEEP
USB	TV/DTV
AUTO	/ NET TV
PAUSE	⏸
STOP	■ / SMART
REW	GREEN

ORIGINAL	SUPERIOR
PLAY	YELLOW
FWD	BLUE
KEY+	SHIFT+UP
KEY -	SHIFT+DOWN
RED	SHIFT+RED
GREEN	SHIFT+GREEN
YELLOW	SHIFT+YELLOW
BLUE	SHIFT+BLUE