ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
⌂ / HOME	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ FUNCTION	/ SOURCE
OPTICAL	-/--
SPEAKER LEVEL	
SOUND EFFECT	
DISC MENU	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
PRESET NEXT / UP	UP
PRESET PREV / DOWN	DOWN
TUNING - / LEFT	LEFT
TUNING+ / RIGHT	RIGHT
ENTER	OK
/ BACK	BACK
SLEEP	SLEEP
INFO / MENU	INFO
MUSIC ID	EPG
3D SOUND	FAV
OPEN / CLOSE	/ NET TV

ORIGINAL	SUPERIOR
RED / RDS	RED
GREEN / PTY	GREEN
YELLOW / PTY SEARCH	YELLOW
BLUE / MONO/STEREO	BLUE
AUDIO	SHIFT+MUTE
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
/ REPEAT	SHIFT+BACK
TITLE / POP UP	SHIFT+INFO
PAUSE	SHIFT+ ⏸
STOP	SHIFT+ ■
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE