ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
AUTO POWER ON	1
AUTO POWER OFF	0
F	/ SOURCE
ASC	-/--
CINEMA	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
WOOFER LEVEL+	UP
WOOFER LEVEL -	DOWN
STANDARD	FAV
PLAY / PAUSE	YELLOW

ORIGINAL	SUPERIOR