ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
DRC ON	1
WOOFER LEVEL+	2
AUTO POWER ON	3
DRC OFF	4
WOOFER LEVEL -	5
AUTO POWER OFF	6
F	/ SOURCE
VOL+	VOL+
VOL -	VOL -
CINEMA	TV/DTV
ASC	EPG
STANDARD	FAV

ORIGINAL	SUPERIOR