| ORIGINAL | SUPERIOR |
|---|---|
| POWER | POWER |
| / AUDIO | MUTE |
| / HOME | MENU |
| CLEAR | EXIT |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| DISC MENU | -/-- |
| DISPLAY | |
| ZOOM | |
| SUBTITLE ON/OFF | |
| / SUBTITLE | |
| SKIP NEXT | P+ |
| SKIP PREV | P - |
| UP | UP |
| DOWN | DOWN |
| LEFT | LEFT |
| RIGHT | RIGHT |
| OK | OK |
| / RETURN | BACK |
| PIC MODE | SLEEP |
| TITLE / POPUP | INFO |
| RESOLUTION | EPG |
| MARKER | FAV |
| OPEN / CLOSE | / NET TV |
| PAUSE | |

| ORIGINAL | SUPERIOR |
|---|---|
| STOP | / SMART |
| REW | GREEN |
| PLAY | YELLOW |
| FWD | BLUE |
| SEARCH | SHIFT+EXIT |
| REPEAT | SHIFT+BACK |
| RED / A | SHIFT+RED |
| GREEN / B | SHIFT+GREEN |
| YELLOW / C | SHIFT+YELLOW |
| BLUE / D | SHIFT+BLUE |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |