ORIGINAL	SUPERIOR
POWER	POWER
VISS	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV	/ SOURCE
C.LOCK	-/--
SHOWVIEW	
VISS	
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK / CLK/CNT	OK
CM SKIP	BACK
TV/VCR	TV/DTV
i	INFO
EJECT	/ NET TV
P/STILL	/ SMART TUBE
STOP	/ SMART VIDEO
REC/OSR	RED
REW	GREEN
PLAY	YELLOW
FWD	BLUE

ORIGINAL	SUPERIOR