ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
TAPE 1	1
TAPE 2	2
AUX	3
CD	4
TUNER / BAND	5
INPUT NEXT	/ SOURCE
EQ. PATT.	
VOLUME+	VOL+
VOLUME -	VOL -
PREV TRACK	LEFT
NEXT TRACK	RIGHT
REPEAT	BACK
SLEEP	SLEEP
PAUSE	
STOP	/ SMART
REW/SKIP PREV	GREEN
PLAY	YELLOW
FWD/SKIP NEXT	BLUE
TAPE PLAY REV.	SHIFT+LEFT
TAPE STOP	SHIFT+
TAPE REC	SHIFT+RED
TAPE REW	SHIFT+GREEN
TAPE PLAY	SHIFT+YELLOW

ORIGINAL	SUPERIOR
TAPE F. FWD	SHIFT+BLUE