ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
/ HOME	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
RADIO & INPUT	/ SOURCE
INFO / DISPLAY	
SOUND EFFECT	
SPEAKER LEVEL	
SEARCH	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP / PRESET+	UP
DOWN / PRESET -	DOWN
LEFT / TUNING -	LEFT
RIGHT / TUNING+	RIGHT
ENTER	OK
/ BACK	BACK
SLEEP	SLEEP
TITLE / POP UP	INFO
MARKER	FAV
USER EQ	EPG

ORIGINAL	SUPERIOR
OPEN / CLOSE	/ NET TV
PAUSE	
STOP	/ SMART
REC	RED
SCAN REW	GREEN
PLAY	YELLOW
SCAN FWD	BLUE
DISC MENU	SHIFT+MENU
OPTICAL	SHIFT+
/ REPEAT	SHIFT+BACK
RED / R / RDS	SHIFT+RED
GREEN / G / PTY.	SHIFT+GREEN
YELL. / Y / PTY. SEAR.	SHIFT+YELLOW
BLUE / B / MONO/ST.	SHIFT+BLUE