

ORIGINAL	SUPERIOR
CANCEL	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
EDIT	-/--
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
REPEAT	BACK
TIME	SLEEP
RANDOM	TV/DTV
DIMMER	INFO
PROG	EPG
A – B	FAV
OPEN/CLOSE	⏏ / NET TV
PAUSE	⏸ / SMART TUBE
STOP	■ / SMART VIDEO
REW	GREEN
PLAY	YELLOW
FWD	BLUE

ORIGINAL	SUPERIOR