ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
CBL/SAT	1
DVD	2
BLU – RAY	3
GAME	4
AUX 1	5
MEDIA PLAYER	6
TV AUDIO	7
AUX 2	8
TUNER	9
IPOD/USB	0
CD	/ SOURCE
BLUETOOTH	-/--
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT / TUNE+	P+
SKIP PREV / TUNE -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
BACK	BACK
SLEEP	SLEEP

ORIGINAL	SUPERIOR
PHONO	TV/DTV
ONLINE MUSIC	/ NET TV
INTERNET RADIO	/ SMART
PLAY/PAUSE	YELLOW
SMART SELECTOR 1	SHIFT+1
SMART SELECTOR 2	SHIFT+2
SMART SELECTOR 3	SHIFT+3
SMART SELECTOR 4	SHIFT+4
CH/PAGE+	SHIFT+ P+
CH/PAGE -	SHIFT+ P -