| ORIGINAL | REPLACEMENT |
|---|---|
| POWER | POWER |
| MUTE | MUTE |
| INDEX | MENU |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| VCR | AV |
| LOCK | -/-- |
| UP | UP |
| DOWN | DOWN |
| LEFT | LEFT |
| RIGHT | RIGHT |
| STORE | OK |
| TV | TV/DTV |
| TV/RADIO | SHIFT+TV/DTV |
| AUDIO | SHIFT+MUTE |
| TIMER | SLEEP |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| ORIGINAL | REPLACEMENT |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |