ORIGINAL	SUPERIOR
POWER	POWER
1/2/3/4/5	1/2/3/4/5
6/7/8/9	6/7/8/9
0 / AV	0
+ / -	-/--
FRAME ADV.	P+
REV. PLAY	P-
SLOW – -	LEFT
SLOW – +	RIGHT
SLOW	OK
RESET	BACK
CLOCK / COUNTER	SLEEP
TIME SEARCH	INFO
MEMORY / SEARCH	EPG
PAUSE / STILL	⏸
STOP	■
REC.	RED
REW / ◀◀	GREEN
PLAY	YELLOW
▶▶ / FF	BLUE

ORIGINAL	SUPERIOR