ORIGINAL	SUPERIOR
POWER	POWER
AUDIO / MUTE	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SMRT PICTURE	
SKIP SEARCH	
SPEED	
REC END SEARCH	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK / STATUS	OK
TIMER	SLEEP
VCR / TV	TV/DTV
TURBO TIMER	INFO
PAUSE	
STOP	/ SMART
REC /OTR	RED
REW	GREEN
PLAY	YELLOW

ORIGINAL	SUPERIOR
FWD	BLUE
CH+	SHIFT+ P+
CH -	SHIFT+ P -