

ORIGINAL	SUPERIOR
STANDBY / ON	POWER
CLR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9	6/7/8/9
0 / 10	0
>10	-/--
DISP.	
VOL+	VOL+
VOL -	VOL -
NEXT TRACK	P+
PREV TRACK	P -
NEXT DISC	UP
SKIP PREV	LEFT
SKIP NEXT	RIGHT
REPEAT	BACK
SLEEP	SLEEP
PROGRAM	EPG
EJECT	/ NET TV
PAUSE	
STOP	/ SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE
TUNER	SHIFT+1
CD	SHIFT+2

ORIGINAL	SUPERIOR
TAPE	SHIFT+3
MONO	SHIFT+4