ORIGINAL	SUPERIOR
STANDBY/ON	POWER
AUDIO	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
PLAY MODE	/ SOURCE
DISPLAY	
ZOOM	
ANGLE	
SUBTITLE	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
HOME MENU	EPG
TOP MENU	FAV
OPEN/CLOSE	/ NET TV
PAUSE	
STOP	/ SMART
REW	GREEN

ORIGINAL	SUPERIOR
PLAY	YELLOW
FWD	BLUE