

ORIGINAL	SUPERIOR
POWER	POWER
MENU	MENU
EXIT	EXIT
MOVIE	
ASPECT	
DYNAMIC	
GAMMA	
CONTRAST +	VOL+
CONTRAST -	VOL-
COLOR +	SHIFT+UP
COLOR -	SHIFT+DOWN
BRIGHTNESS+	GREEN
BRIGHTNESS-	BLUE
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
COLOR TEMP	SHIFT+OK
COMPONENT	1
HDMI1	2
HDMI2	3
S-VIDEO	4
VIDEO	5
HIDE	6

ORIGINAL	SUPERIOR
SHARP DOWN	8
SHARP UP	9
TEST	0
POWER OFF	SHIFT+POWER