ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
CLEAR	EXIT
INPUT	/ SOURCE
TIMER	-/--
DISPLAY	▭
VOL+	VOL+
VOL -	VOL -
FWD/SKIP NEXT	P+
REW/SKIP PREV	P -
UP	UP
DOWN	DOWN
REPEAT	BACK
REPEAT/ST – MONO	SLEEP
EQ	TV/DTV
P. BASS	EPG
STOP	■ / SMART VIDEO
PLAY/PAUSE	YELLOW

ORIGINAL	SUPERIOR