ORIGINAL	SUPERIOR
STANDBY	POWER
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DVD/USB	/ SOURCE
+10	-/--
ZOOM	
SUBTITLE	
+	VOL+
-	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
REPEAT	BACK
SLOW	SLEEP
ANGLE	EPG
A – B	FAV
OPEN/CLOSE	/ NET TV
STOP	/ SMART VIDEO
REW	GREEN

ORIGINAL	SUPERIOR
PLAY/PAUSE	YELLOW
REW	BLUE
AUDIO	SHIFT+MUTE