ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
↵ / MENU / SET	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV / VIDEO	AV
V. SIZE	▭
PIP	⧉
TEXT	▤
VOL+	VOL+
VOL-	VOL-
PG+	P+
PG-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
PRE. PG.	BACK
⧗ / SLEEP	SLEEP
? / SOUND	TV/DTV
i / TIME	INFO
PG. INFO	EPG
⇕ / BRIGHT.	FAV
PICTURE	▲

ORIGINAL	SUPERIOR
STILL	⏸
RED / ERASE	RED
GREEN / SKIP	GREEN
YELLOW / INSERT	YELLOW
BLUE / REPLACE	BLUE
MTS	SHIFT+MUTE