ORIGINAL	SUPERIOR
⏻	POWER
AUDIO	MUTE
⌂ / HOME	MENU
⇥ / EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
POP-UP / TITLE MENU	-/--
FULL SCREEN	▭
BONUS VIEW	⊞
/ TOOLS	▤
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
↵	OK
↺ / RETURN	BACK
i / INFO	INFO
DISC MENU	EPG
EJECT	⏏ / NET TV
PAUSE	⏸
STOP	■ / SMART
REW	GREEN
PLAY	YELLOW

ORIGINAL	SUPERIOR
FWD	BLUE
SUBTITLE	SHIFT+
REPEAT	SHIFT+BACK
REPEAT A – B	SHIFT+SLEEP
RED / A	SHIFT+RED
GREEN / B	SHIFT+GREEN
YELLOW / C	SHIFT+YELLOW
BLUE / D	SHIFT+BLUE
TV	
⏻	SHIFT+POWER
/ SOURCE	/ SOURCE
VOL+	VOL+
VOL -	VOL -