ORIGINAL	SUPERIOR
POWER	POWER
/ MENU	MENU
/ EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ SMART HUB	/ SOURCE
/ CH. LIST	-/--
FULL SCREEN	
2D → 3D	
TTX / MIX	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
	OK
/ RETURN	BACK
AD / SUBTITLE	TV/DTV
/ INFO	INFO
/ GUIDE	EPG
POPUP / TITLE MENU	FAV
EJECT	/ NET TV
PAUSE / TIMESHIFT	/ SMART TUBE
STOP	/ SMART VIDEO

ORIGINAL	SUPERIOR
REC	RED
REW	GREEN
PLAY / TIMESHIFT	YELLOW
FWD	BLUE
DISC MENU	SHIFT+MENU
/ TOOLS	SHIFT+
PROG+ / NEXT PAGE	SHIFT+ P+
PROG - / PREV PAGE	SHIFT+ P -
SEARCH	SHIFT+INFO
REC. PAUSE	SHIFT+
RED / A	SHIFT+RED
GREEN / B	SHIFT+GREEN
YELLOW / C	SHIFT+YELLOW
BLUE / D	SHIFT+BLUE