ORIGINAL	SUPERIOR
POWER	POWER
AUDIO	MUTE
/ MENU	MENU
SEARCH	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
+10	-/--
ZOOM	
	VOL+
	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
	OK
/ RETURN	BACK
ALARM	SLEEP
MODE	TV/DTV
BACKUP	EPG
PRESET	FAV
FREEZE	
HOLD	/ SMART

ORIGINAL	SUPERIOR
REC	RED
REW	GREEN
PLAY/PAUSE	YELLOW
FWD	BLUE