ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
AUX	1
BLUETOOTH	2
LINE IN	3
OPTICAL	4
MOVIE	
DIALOG	
MUSIC	
VOL+	VOL+
VOL-	VOL-
SKIP NEXT	P+
SKIP PREV.	P-
BASS+	UP
BASS-	DOWN
TREBLE-	LEFT
TREBLE+	RIGHT
PLAY / PAUSE	YELLOW

ORIGINAL	SUPERIOR