ORIGINAL	SUPERIOR
⏻	POWER
MENU	MENU
ESC	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SKY	/ SOURCE
PRIMAFILA	
INTERATTIVI	
TXT	
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
TV	TV/DTV
i	INFO
GUIDA TV	EPG
MY	FAV
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
PAUSE	SHIFT+

ORIGINAL	SUPERIOR
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE