| ORIGINAL | SUPERIOR |
|---|---|
| | POWER |
| | MUTE |
| | MENU |
| | EXIT |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| | / SOURCE |
| | -/-- |
| | |
| | |
| | |
| TXT | |
| VOL+ | VOL+ |
| VOL - | VOL - |
| P+ | P+ |
| P - | P - |
| UP | UP |
| DOWN | DOWN |
| LEFT | LEFT |
| RIGHT | RIGHT |
| OK | OK |
| | BACK |
| | SLEEP |
| | TV/DTV |
| INFO | INFO |

| ORIGINAL | SUPERIOR |
|---|---|
| EPG | EPG |
| FAV | FAV |
| RED | RED |
| GREEN | GREEN |
| YELLOW | YELLOW |
| BLUE | BLUE |
| | SHIFT+ |
| RECALL | SHIFT+BACK |
| STOP | SHIFT+ |
| REC | SHIFT+RED |
| REW | SHIFT+GREEN |
| PLAY | SHIFT+YELLOW |
| FWD | SHFIT+BLUE |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |