ORIGINAL	SUPERIOR
POWER	POWER
MUTING / -20dB	MUTE
CANCEL	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
CD	/ SOURCE
> 10	-/--
DECK 1/2	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
SLEEP	SLEEP
TUNER/BAND	TV/DTV
PROGRAM	EPG
FM MODE	FAV
PAUSE	/ SMART TUBE
STOP	/ SMART VIDEO
REW	GREEN
PLAY	YELLOW
FWD	BLUE
TAPE STOP	SHIFT+
TAPE PLAY	SHIFT+YELLOW

ORIGINAL	SUPERIOR