ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
APS	MENU
SEARCH	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
10+	-/--
DISPLAY	▭
BALANCE	⊟
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
SOURCE+	UP
SOURCE -	DOWN
STATION -	LEFT
STATION+	RIGHT
REPEAT	BACK
TONE	SLEEP
FM ST / M	TV/DTV
MEM	EPG
AUTO	FAV
EJECT	⏏ / NET TV
STOP	■ / SMART
REW	GREEN

ORIGINAL	SUPERIOR
PLAY / PAUSE	YELLOW
FWD	BLUE