ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
VOL+	VOL+
VOL -	VOL -
SKIP NEXT / CH+	P+
SKIP PREV / CH -	P -
⮌	BACK
EQ	TV/DTV
SCAN	INFO
REP	FAV
PLAY/PAUSE	YELLOW

ORIGINAL	SUPERIOR