ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
MENU	MENU
OFF	EXIT
INPUT 1 – 3	1
HDMI 1 – 3	2
TV	3
CH LEVEL	-/--
MOVIE	
DOCK	
SETUP	
OPTION	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
SLEEP	SLEEP
STEREO	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
ENHANCER	EPG
ENTERTAINMENT	FAV
SUBWOOFER -	GREEN
PLAY / PAUSE	YELLOW
SUBWOOFER+	BLUE
MUSIC	SHIFT+MUTE
SURROUND	SHIFT+
UNIVOLUME	SHIFT+